


Face Plate



Switching Angle

90

Total switching Angle

30



OFF

0

ON

30

45

60

75

90

105

120

135

150

165

180

195

210

225

240

255

270

285

300

315

330

345

Jumpers

1 ●	○ 3	4 ○	● 2
5 ○	○ 7	8 ○	○ 6
9 ○	○ 11	12 ○	○ 10
13 ○	○ 15	16 ○	○ 14
17 ○	○ 19	20 ○	○ 18
21 ○	○ 23	24 ○	○ 22
25 ○	○ 27	28 ○	○ 26
29 ○	○ 31	32 ○	○ 30
33 ○	○ 35	36 ○	○ 34
37 ○	○ 39	40 ○	○ 38
41 ○	○ 43	44 ○	○ 42
45 ○	○ 47	48 ○	○ 46