


Face Plate



Switching Angle

30

Total switching Angle

30



1	3	5	7	9	11	13	15	17	19	21	23
2	4	6	8	10	12	14	16	18	20	22	24
0	0										
	15										
1	30										
	45										
	60										
	75										
	90										
	105										
	120										
	135										
	150										
	165										
	180										
	195										
	210										
	225										
	240										
	255										
	270										
	285										
	300										
	315										
	330										
	345										

Jumpers

1 ●	○3	4○	●2
5○	○7	8○	○6
9○	○11	12○	○10
13○	○15	16○	○14
17○	○19	20○	○18
21○	○23	24○	○22
25○	○27	28○	○26
29○	○31	32○	○30
33○	○35	36○	○34
37○	○39	40○	○38
41○	○43	44○	○42
45○	○47	48○	○46