




CG8

A715 VE

Page 1 of 1

Face Plate



Switching Angle

30

Total switching Angle

60

2	4	6	8	10	12	14	16	18	20	22	24
---	---	---	---	----	----	----	----	----	----	----	----

[illegible]

Jumpers

1 ●	3 ●	4 ●	2 ●
5 ●	7 ●	8 ●	6 ●
9 ○	11 ○	12 ○	10 ○
13 ○	15 ○	16 ○	14 ○
17 ○	19 ○	20 ○	18 ○
21 ○	23 ○	24 ○	22 ○
25 ○	27 ○	28 ○	26 ○
29 ○	31 ○	32 ○	30 ○
33 ○	35 ○	36 ○	34 ○
37 ○	39 ○	40 ○	38 ○
41 ○	43 ○	44 ○	42 ○
45 ○	47 ○	48 ○	46 ○